Carry out an firmware update of your´s DVB SD/HD IRD

To avoid data loss, we would therefore recommend to save the A/V-Stettings and the Channellist with the BoxEdit-software. (Picture 1)



Pic 1

Pic 2

Pic 3

Current firmware updates can be found in ELIUM website:

http://www.elium.de/files/download/Boxedit.exe
http://www.elium.de/files/download/elium_ird_update.zip

http://www.elium.de/files/download/IRD_RS232_Protocol.pdf

The usb drive with a ***minimal 50 MB*** free space available should be used for the firmware update.
Before you write image with the firmware to your usb drive, it should be formatted to FAT 32 format. (Picture 2 and 3)

1. Save the selected firmware update to your USB drive.
   Make sure that the Zip archive is unpacked.

2. **Software ver. 1.02.04 and older:**
   Please plug the USB drive in the USB slot on the frontsite of the unit. Press the Menu-Button with the romotecontroll or over the Webserver ->Technical Menu -> Restart
   -> Reboot IRD -> OK.
   (You can also operate with button on the frontsite of the unit. You see the Menu-settings on the Display.)
   Don`t shut down the unit in the update process, because it could be that you get a abend of the compleadly software

2. **from Software ver .1.02.05**
   Please plug the USB drive in the USB slot on the frontsite of the unit.
   The update will be start automatically after 30 sec..

3. When update completes „**Flashing ... OK**“ prompt appears on LCD. Now remove the usb drive from the unit and restart the device, with the OFF/ON switch in front of the unit.

4. Please confirm the reboot by pushing the OK button once, after it´s promted on LCD.
   The automatical Reboot will start after over 10 second.